



All the music you want. All over your house.

Sonos Controller

CR100



Instantly access all your music and rooms from the palm of your hand.

The Sonos® Controller gives you instant, wireless access to all your music and all your rooms. SonosNet™, our wireless mesh network technology, ensures that every Controller works wirelessly, all over the house, so you don't have to run back and forth to your computer. Instead, you can choose exactly what to play and where to play it from anywhere — sitting on the couch or cooking in the kitchen.

With the Controller in hand you can find and play music from your personal music collection, Internet radio and the most popular online music services. And using the Controller couldn't be easier. Just pick a room, pick a song and hit play. Use search to find your favourites, and quickly link and unlink zones to play the same song in every room or different songs in different rooms. Controllers aren't tied to a specific ZonePlayer™, so you can use any Controller to control the music — and the volume — in any or all rooms. And there's practically no limit to how many Controllers you can have — one for every room, floor or music lover in your house.

Key Features

- Wireless, multi-room control from the palm of your hand
- Instant access to endless music
- Easy and fun to use
- In full colour, indoors and out
- New features and music services with automatic updates

Sonos Controller



Wireless, multi-room control from the palm of your hand

Control all your music and all your ZonePlayers from the palm of your hand. The Sonos Controller goes where your computers and IR remotes can't. One Sonos Controller can control any Sonos product in your system, so you can move around the house and stay in complete control over your multi-room music experience.



Instant access to endless music

With the Controller in hand, you can find and play any song from your personal collection of music stored on your computer, thousands of free Internet radio stations and millions of songs from the most popular online music services.



Easy and fun to use

When it comes to scrolling through music libraries, searching for songs, viewing album art, choosing zones, and more, the Sonos Controller makes it all incredibly easy. Just pick a room, pick a song and hit play to let the fun begin.



In full colour, indoors and out

The full-colour LCD display makes everything on the screen bright and easy to see, whether it's album artwork, song titles, or artist names. And because you can enjoy your music anywhere, the screen is optimised for indoor and outdoor use.



New features and music services with automatic updates

With free automatic software updates, you'll always have the newest features and music services to enjoy. Which means your system will keep getting better even after you buy.



TECHNICAL SPECIFICATIONS

Screen

3.5" (diagonal) colour transfective LCD screen with LED backlighting, 240 x 320 (QVGA)

Browse control

Touch-sensitive scroll wheel with centre-mounted selector button

Function buttons

9 backlit buttons, 3 soft-selector buttons below screen

Battery

High density rechargeable Li-ION Polymer battery, factory-replaceable

Wireless connectivity*

SonosNet 1.0, a secure AES encrypted, peer-to-peer wireless mesh network

DC charger

Input 100-240 VAC, 50-60 Hz; Output 6 VDC, 3.8A

Dimensions/weight

6.5 x 3.8 x 0.95 in (165 x 97 x 24.5 mm)/12.5 oz (360 g)

*Internet connection required for access to Internet radio stations, online music services and software updates (DSL, cable modem or LAN-based high-speed Internet connection required.) Internet functionality may require payment of separate fee to a service provider.

Sonos Charging Cradle 100

Designed to hold and charge your Sonos Controller. (Sold separately.)

When the Controller is in the Cradle, it remains fully functional...not to mention easy to find. Use the AC Adapter that comes with every Controller for power. Then mount it on the wall or place it on a table.

Colour/material

Light gray/high quality PC grade colour matched to the Controller.
Blue rubber padding on bottom to provide firm grip.

Dimensions/weight

2.6 x 2.2 x 7.4 in (65 x 57 x 189 mm) /7.1 oz (200 g)



Note: All specifications subject to change without notice.

© 2004-2008 by Sonos Inc.

All rights reserved. Sonos is a registered trademark of Sonos, Inc. in the United States, Canada and Australia, and a trademark of Sonos, Inc. in other countries. SonosNet, ZonePlayer, ZoneBridge and all Sonos logos are trademarks of Sonos Inc. in the United States and other countries. All other products and services may be trademarks or servicemarks of their respective owners.



All the music you want. All over your house.

www.sonos.com